01234 215407 • SALES@BANNER-UK.COM
WWW.SWAGINGMACHINES.COM

QUICK CHANGE CLUSTER SYSTEM



How to speed up die changes – A new approach to an old problem

The new Banner Quick Change Cluster System allows complete die set to be easily and safely removed and replaced in a matter of seconds.

FEATURES

- No tooling required to load die
- Die loaded by hand
- New system can be fitted to old machines without new parts to be fitted to the old machines
- Spare kit can be offered if required
- New system can be fitted by yourself and does not have to be factory fitted

AVAILABLE FOR:

- BS10H
- BS10VM
- BS16H
- BS16VM
- BS20M
- BS24-40B
- BS32M
- BS23-50B
- BS20MF
- BS20F
- BS32-50HDB
- BS32F
- BS32MF
- BS32-50HDF



QCCS-10/16

Banner Quick Change Cluster System for BS10/BS16 systems.

Suitable for BS10, BS10VM, BS16, BS16VM.

USAGE

- Insert the required die
- Make sure the die is level with the front of the die holders
- Insert fitting
- Crimp to the required size
- Insert elbow fitting or insert elbow through die
- Insert die and fittings into machine



QCCS-20/32

Banner Quick Change Cluster System for BS20/BS32 systems.

Suitable for BS20M, BS24/40B, BS32M, BS32/50B, BS20MF, BS20F, BS32MF, BS32F, BS32/50HDB, BS32/HDF, BS32-50F-IND

USAGE

- Get required die from tool box. Find location pin on die.
- Insert die into machine lining up location pin into bottom die holder
- Set machine to required size then crimp
- Insert elbow through die
- Die & elbow ready for machine
- Insert die & fitting onto machine by lining up location pin into bottom die holder
- Set machine to required size and then crimp